



M COLLECTION - CRANK HEIGHT ADJUSTABLE TABLE (THICK CROSS-LINK)

INSTALLATION INSTRUCTIONS


WORK SURFACE SHAPES:




PRODUCTS:



TOOLS REQUIRED:



3/16" ALLEN WRENCH




POWER SCREWDRIVER

#3 PHILLIPS DRIVER TIP


PARTS INCLUDED:

A WORKSURFACE
(SEE SHAPES ABOVE)


B CRANK BASE ASSEMBLY
QTY: ONE (1)




C FOOT ASSEMBLIES
QTY: TWO (2)



OR




OR



D COLUMN COVER INSERTS
QTY: FOUR (4)


D1 OUTSIDE (LARGE)
QTY: TWO (2)

D2 INSIDE (SHORT)
QTY: TWO (2)




SOLID STEEL SHOWN

D1 OUTSIDE MAY BE PERFORATED




"RAIN" PERFORATION




"CITY BLOCK" PERFORATION


E 5/16-18 X 1 1/4" BUTTON HEAD
SOCKET CAP SCREW
QTY: FOUR (4)




F #12 X 1 1/8" PAN HEAD SCREW
QTY: TEN (10)




G CRANK HANDLE GROMMET
QTY: ONE (1)



H CRANK HANDLE
QTY: ONE (1)



I CORD CLIP
QTY: TWO (2)




M COLLECTION - CRANK HEIGHT ADJUSTABLE TABLE (THICK CROSS-LINK)

INSTALLATION INSTRUCTIONS


P/N 21133-01 SHEET 2 OF 4

PROCEDURE:


- 1.** LAY WORK SURFACE UPSIDE DOWN ON A CLEAN SURFACE AND POSITION BASE OVER PRE-DRILLED HOLES. THE VERTICAL SLOTS IN THE REAR OF THE COLUMNS SHOULD FACE THE REAR EDGE OF THE WORK SURFACE. ATTACH BASE TO WORK SURFACE USING FIVE (5) # 12 X 1 1/8" PAN HEAD SCREWS IN EACH TOP MOUNTING BRACKET.



- 2.** INSERT COLUMN COVERS INTO BOTH SIDES OF EACH COLUMN. INSTALL WITH NOTCHES AT ENDS OF COVERS AWAY FROM WORK SURFACE. IF PERFORATED COVERS ARE SUPPLIED, INSTALL WITH PERFORATIONS TO THE OUTSIDE.



- 3.** ATTACH THE FEET USING TWO (2) 5/16-18 X 1 1/4" BUTTON HEAD SOCKET CAP SCREWS PER COLUMN. USE FRONT MOUNTING HOLES IN FEET.




M COLLECTION - CRANK HEIGHT ADJUSTABLE TABLE (THICK CROSS-LINK)

INSTALLATION INSTRUCTIONS

P/N 21133-01 SHEET 3 OF 4

PROCEDURE (CONT):

- 4.** CORD CLIPS SNAP FIT INTO VERTICAL SLOT IN REAR OF COLUMNS




NOTICE


The following instructions are for installing a Keyboard Mechanism on a Dual Surface table. If installing a Single Surface table, proceed to Step 7 of these instructions.

PARTS INCLUDED FOR DUAL SURFACE TABLE (PACKED WITH KEYBOARD MECHANISM):

- J** KEYBOARD MECHANISM
QTY: ONE (1)



- K** #12 X 1 1/8" PAN HEAD SCREW
QTY: TEN (10)



- L** #8 X 3/4" PAN HEAD SCREW
QTY: FOUR (4)




- M** #8 X 1/2" PAN HEAD SCREW
QTY: TWO (2)



- N** CABLE CLAMP 1/4"
QTY: TWO (2)




- O** MOUSE RETAINER
QTY: ONE (1)



PROCEDURE (CONT):

DUAL SURFACE TABLE KEYBOARD MECHANISM INSTALLATION:

- 5.** LAY KEYBOARD SURFACE UPSIDE DOWN IN FRONT OF MONITOR SURFACE WITH SLOTS TOWARD FRONT OF TABLE. POSITION KEYBOARD MECHANISM OVER PRE-DRILLED HOLES. ATTACH KEYBOARD ARM TO MONITOR SURFACE USING TWO (2) #12 X 1 1/8" PAN HEAD SCREWS ON ONE SIDE AND FOUR (4) ON THE OTHER SIDE (AS SHOWN). ATTACH KEYBOARD SURFACE USING TWO (2) #12 X 1 1/8" PAN HEAD SCREWS ON EACH SIDE.




M COLLECTION - CRANK HEIGHT ADJUSTABLE TABLE (THICK CROSS-LINK)

INSTALLATION INSTRUCTIONS


PROCEDURE (CON'T):

DUAL SURFACE TABLE KEYBOARD MECHANISM INSTALLATION:

- 6.** INSERT KEYBOARD BRAKE RELEASE IN SLOT (AS SHOWN). ATTACH WITH TWO (2) #8 X 3/4" PAN HEAD SCREWS. PLACE ONE (1) PLASTIC CABLE CLAMP ON CABLE APPROXIMATELY 1" BEHIND RELEASE HANDLE AND SECURE WITH ONE (1) #8 X 3/4" PAN HEAD SCREW. IF NECESSARY, FORM A LOOP WITH EXCESS CABLE AND SECURE WITH PLASTIC CABLE CLAMP AND ONE (1) #8 X 3/4" PAN HEAD SCREW.




- 7.** STAND THE TABLE UPRIGHT AND MOVE INTO POSITION MAINTAINING PROPER CLEARANCE WITH ADJACENT SURFACES. ADJUST THE GLIDES TO LEVEL THE SURFACE.



NOTICE

If dual surface, adjust the keyboard up and down to ensure that the cable does not bind or restrict travel.



NOTICE

Mouse retainer is optional and is normally installed on the back of the keyboard surface. The mouse retainer is a press fit or can be attached using two (2) #8 x 1/2" pan head screws.

- 8.** PLACE GROMMET IN HOLE FOR CRANK HANDLE. PLACE CRANK HANDLE ON HEX DRIVE.

