


NEXT - FIXED TABLE - 2 LEG BASE - WITH MY STUDIO LEG


INSTALLATION INSTRUCTIONS

P/N 22383-01 SHEET 1 OF 2


WORK SURFACE SHAPES:



PRODUCTS:




TOOLS REQUIRED:



POWER SCREWDRIVER

#2 PHILLIPS DRIVER TIP
#3 PHILLIPS DRIVER TIP




1/2" OPEN END WRENCH


PARTS INCLUDED:

A WORKSURFACE
(SEE SHAPES ABOVE)


B FIXED LEG ASSEMBLY
QTY: ONE (1)




C FIXED LEG ASSEMBLY - MY STUDIO
QTY: ONE (1)



D TOP STIFFENERS
QTY: NONE, OR TWO (2)




E #12 X 1 1/8" PAN HEAD SCREW
QTY: THIRTY-SIX (36)



PROCEDURE:

- 1.** LAY WORK SURFACE UPSIDE DOWN ON A CLEAN SURFACE AND POSITION LEGS OVER PRE-DRILLED HOLES. ORIENT THE LEGS SO THAT THE CASTERS ARE TOWARD THE REAR EDGE OF THE WORK SURFACE AND GLIDES TOWARD THE FRONT EDGE OF THE WORK SURFACE. ATTACH LEGS TO WORK SURFACE USING EIGHT (8) # 12 X 1 1/8" PAN HEAD SCREWS IN EACH TOP MOUNTING BRACKET.




NEXT - FIXED TABLE - 2 LEG BASE - WITH MY STUDIO LEG


INSTALLATION INSTRUCTIONS

PROCEDURE (CONTINUED):


- 2.** IF TOP STIFFENERS ARE INCLUDED WITH THE TABLE, POSITION THE STIFFENERS OVER THE PRE-DRILLED HOLES IN THE WORK SURFACE. ATTACH STIFFENERS TO WORK SURFACE USING #12 X 1 1/8" PAN HEAD SCREWS.



- 3.** STAND THE TABLE UPRIGHT AND MOVE INTO POSITION MAINTAINING PROPER CLEARANCE WITH ADJACENT SURFACES.



- 4.** ADJUST THE GLIDES ON THE FRONT OF THE FOOT AND CASTERS ON THE REAR TO LEVEL THE WORK SURFACE



NOTICE

After adjusting the height of the caster, tighten the jam nut against the bottom of the foot.

NOTICE

The glide includes a jam nut that can be tightened against the bottom of the foot to lock the height adjustment.